



One Step DVD

MiniDV to DVD



Problem Solving

1. Sometimes the computer doesn't recognize that the camcorder is plugged in, so you may need to restart the computer after you have plugged the camcorder in and turned it on.
2. If you have sound recorded with and without the external microphone, you may need to use iMovie & iDVD to do the transfer.